



INSTRUCTIONS FOR APPLICATION

1. Place FABRI-LOC® between the 2 layers of fabric to be fused together. CAUTION: FABRI-LOC® must not overlap beyond the fabric being fused together as it will adhere to the press or iron.
2. Apply steam or dry heat and pressure for a full 10 seconds:
 - A. Steam press at operating temperature
 - B. Hand iron, steam or dry heat at wool or 325°F.
3. Turn the fabric over and again apply heat and pressure to the other side of the fabric for a full 10 seconds.
4. Allow to cool. Test bond for proper adhesion. If necessary, repeat steps 2 and 3.

WARNING: If hand iron is used, a pressing cloth may be required to prevent scorching. DO NOT SLIDE OR TWIST HAND IRON BACK AND FORTH. HOLD STATIONARY.

NOTE: To release a bond made with FABRI-LOC®, simply repeat step 2 and separate fabric layers while hot. To remove any FABRI-LOC® residue, heat the fabric and apply methyl alcohol (wood alcohol). Use a bone scraper and gently scrape away the visible adhesive residue which has permeated the fabric. Do not heat solvent on fabric.